

KRYSTALKRETE

EXPOSED AGGREGATE POOL FINISH

Product Application Sheet

Pool Shell Preparation

The interior cementitious finish of a pool is the only cosmetic part of a pool that is handcrafted in an uncontrolled environment. For this reason it is **absolutely imperative** that supervision of the shell and shell preparation prior to plastering be carefully monitored and any questionable areas corrected. This includes:

NEW CONSTRUCTION

- Step 1.** High or low spots in the shell **need** to be ground down or filled to help the applicators apply a consistent $\frac{3}{8}$ inch (approximate minimum) finish thickness. Hydration problems can occur if the finish is applied too thick or too thin.
- Step 2.** Weepers, return and suction lines penetrations **must** be sealed with hydraulic cement at least seven days prior to cleaning and acid washing the pool shell. Possible voids may create leaks and gray streaks.
- Step 3.** After a **minimum 28 day cure**, the pool shell should be de-watered, cleaned, and acid washed. Extremely wet areas in the shell will cure differently and create shaded areas. **Example: A wet bowl can cause a halo around the main drain.**
- Step 4.** The equipment and electric hook up **must** be in place before the final finish is applied. Proper fire-up, immediately following the pool fill helps correct any environmental problems the applicators may experience during the finish application.
- Step 5.** "Where uncontrollable ground water or rainy season is prevalent" a dead line **must** be installed.
- Step 6.** Acid wash, neutralize, and rinse entire pool surface to remove efflorescence, and debris.

Note: The use of a scratch coat is recommended to promote a good bond and even curing when the shell has porosity problems. This includes renovation as well as new construction.



RENOVATION

- Step 7.** Inspect the existing pool surface for degradation and stains. There is usually a reason why these problems occur. Re-plumb chlorinators with a Hartford loop, tether floaters, remove metallic pool fittings including pipe and replace with plastic. Replace bronze gate valves with plastic ball valves, install bypasses on heaters, and discontinue the use of metallic algaecides. If the pool is stained always lower the pH and add a testable sequestering agent to pre-release any existing metal stains that exist within the plumbing system for at least a week. This will help prevent metallic stains from re-staining the new finish. Repair all leaks.
- Step 8.** The use of a scratch coat is recommended to promote even curing and a good bond over an existing finish. Whether shotcrete, gunite, poured, or hand packed, every pool shell is different because of location, environment, and especially the competency of the technicians on the job. **Assume nothing.** Be there and manage the job. The pool contractor is responsible for the entire construction of the pool, start to finish. We are working with a cementitious product that takes up to a year to cure. Follow manufacturer's recommended start-up procedures. Maintenance and operation is also critical during this 10 - 12 month period.

Renovations need inspection and correction of existing troublesome conditions to prevent the same unsightly circumstances from re-occurring.



KrystalKrete® Application

- Step 1.** Prep the pool surface according to manufacturer's recommendations.
- Step 2.** Drain all water from equipment and pipes and/or plug return lines before application. All weepers and plumbing leaks should be repaired at least 24 hours prior to application.
- Step 3.** If calcium chloride is needed, pre-dilute and screen calcium chloride in 5 gallon buckets of water. One for each batch. Excess calcium (1.5%+) causes trapped moisture (graying/hydration), rapid drying causing checking and /or crazing, poor bonding and the inability to close off, working the water, air and fines to the surface.
- Step 4.** Add a measured amount of water to mixer with calcium chloride liquid. Dispose of residue in an environmentally safe manner.
- Step 5.** Add proper number of bags according to mixer capacity. Make sure to box different batch numbers.
- Step 6.** Mix 6 to 8 minutes. Short mix times create a false set; prolonged mix times do not allow enough troweling time.
- Step 7.** Apply evenly (min $\frac{3}{8}$ " , max $\frac{3}{4}$ "). The use of a $\frac{3}{8}$ calibrated rake helps. Material that is too thick (over $\frac{3}{4}$ ") is not effectively troweled unless it is layered. Material that is too thin can dry too rapidly causing cracking and/or crazing.
- Step 8.** Fill in spike holes with aggregate and cement, not just cream.
- Step 9.** Finish trowel for a good bond, and smooth finish as you would a white plaster pool. Hard trowel waterline tile, decorative tile and the seats and steps front and back to eliminate shrinkage.
- Step 10.** During final trowel remove accumulated excess paste with trowel from surface into a bucket for disposal. This will help reveal divots, spike holes, or trowel marks for immediate repair and promote a better exposure. Expose the same day after at least 4 hours of cure time in a warm environment 80 degrees and rising. An overnight cure is not a problem as long as the material is well troweled*.

Note 1: Troweling spreads smooths and compresses the mixture driving the larger aggregates back and bringing the mediums and smaller aggregates forward. At the same time troweling works the cement paste and mix water to the surface reducing the amount of water in the mixture, reducing hydration problems and shrinkage that causes check cracking and/or crazing.

Note 2: In adverse conditions (dry heat, wind, etc.) Mist pool surface to prevent crazing during overnight cure.

Krystalkrete® Exposure Phase (Minimum of 2 Personnel)

Step 1. Mix 1-gallon acid with 3 ounces of acid wash additive (liquid dish detergent such as Dawn).

Example: 6 gallons of acid with 18 ounces of acid wash additive in a 15-gallon carboy or other plastic container. You now have one consistent mix for approx. 800 square feet of surface area walls and floor.

Step 2. Saturate finish with clean fresh water to prevent over penetration of wash down solution. *Keep finish saturated.*

Step 3. Generously sprinkle neutralizing agent (sodium bicarbonate) in approximately an 8-foot diameter around the main drain (the deepest part of the pool).

Step 4. Using an acid resistant garden hose, squirt fresh water backwards into the drum or carboy to prime siphon until bubbles stop. Allow siphoning until acid runs freely. Use a ball valve on the end of the hose for regulation.

Step 5. Place a submersible pump in main drain or the deepest part of the pool, to immediately remove neutralized acid from pool.

Step 6. Keep the walls and floor saturated with fresh water prior to acid washing.

Step 7. Acid wash the walls from the floor up and then the floor from the deepest end to the shallow end.

Step 8. The second man should brush to evenly expose the finish to reduce streaking and troughing.

Using a stiff bristled brush, spot acid wash any remaining pasty areas.

CAUTION: Failure to remove the excess paste in the above procedure will result in an uneven cure causing (graying, blotching, mottling), and other hydration problems associated with poor workmanship. White aggregate pools are more difficult to expose properly because there is no colored quartz aggregate to target. Please follow the directions carefully to achieve the greatest results possible.

Step 9. Thoroughly rinse the pool.

Note: Plastic Sprinklers cans may be used on small pools and spas.

C.L. INDUSTRIES, INC.

P.O. Box 593704 • 8188 S. Orange Ave. • Orlando, Florida 32859-3704
407/851-2660 • 1-800-333-2660

